



NOTES:

1. LOCATE C-9 TERMINATION ABOVE ANTICIPATED WATER LEVEL.
2. FOR CORNER APPLICATIONS, SEE DETAIL C-15.
3. IF A CONTINUATION OF THE DECK MEMBRANE IS TO BE USED AS WALL FLASHING, REFER TO DETAIL C-12.3 OR C-12.4.
4. APPLY LAP SEALANT ALONG THE EDGE OF THE MEMBRANE SPICE (UNDER THE 6" x 6" T-JOINT COVER) COVERING THE EXPOSED SPICE TAPE 2" (50 mm) IN EACH DIRECTION FROM THE SPICE INTERSECTION.
5. 6" (150 mm) WIDE QUICK APPLIED UNCURED EPDM FLASHING MAY ALSO BE CENTERED OVER FIELD SPICE AT ANGLE CHANGE.
6. POLYMER SEAM PLATES ARE REQUIRED IN LIEU OF SEAM FASTENING PLATES FOR MECHANICALLY ATTACHED ROOFING SYSTEMS OVER STEEL DECKS.
7. PRIOR TO INSTALLATION OF QA SEAM TAPE, APPLY VERSICO EPDM PRIMER TO THE SPICE AREA.

C-12.1

PARAPET/CURB CURED EPDM