



NOTE:

USE A HEAT GUN TO WARM QUICK APPLIED UNCURED EPDM FLASHING IN COLD TEMPERATURES.

C-15.3 (OPTION 2) OUTSIDE CORNER  
QUICK APPLIED UNCURED EPDM FLASHING