



NOTES:

1. FOR PROPER MEMBRANE SECUREMENT, REFER TO DETAIL PA-2A.
2. HP PURLIN FASTENERS MUST PENETRATE THE PURLIN A MINIMUM OF 1 INCH.
3. 9" WIDE QA RTS MAY BE USED IN LIEU OF RUSS WITH SPLICING CEMENT. REFER TO DETAIL PA-2B.

PA-22 Versico Mechanically-Attached Roofing System  
 Ridge Membrane Attachment with RTS