

PVC INSIDE CORNERS

GENERAL:

PVC Inside Corners are pre-molded and are used for flashing the inside corners on a variety of details. Installation is fast and easy with no cutting or stretching required. This product is white on gray and can be reversed to use on a gray PVC installation.

TYPICAL PROPERTIES AND CHARACTERISTICS:

| | |
|------------|-----------------|
| Thickness: | .080" (2.03 mm) |
| Color: | White and Gray |

CAUTIONS AND WARNINGS:

1. Store PVC Inside Corners in a cool, shaded area and cover with light-colored, breathable, waterproof tarpaulins. PVC Inside Corners or PVC membrane that have been exposed to the weather must be prepared with PVC Membrane Cleaner prior to hot air welding.

INSTALLATION:

1. Position the PVC Inside Corner into the corner, begin welding at the innermost corner point and work away from the corner.
2. Use a lower temperature setting on the heat welder than when welding reinforced PVC membrane. (Typically a setting of "6" on a scale of "10" is appropriate for welding PVC Inside Corners).
3. Use the edge of the roller to crease the corner flashing into any membrane step-off to create a proper seal.